

# Multivariate process control and real time sensors in practical use


Björn Engström, Perten Instruments AB

Torbjörn Lestander, Swedish University of Agricultural Sciences

Per Lidén, Perten Instruments AB

Henrik Sundström, TPF Management

# Process control



## *Parameters available for process monitoring and optimization*

### *Raw material*

Lab measurements  
Sensors  
Specifications

### *Process*

Automation  
Lab measurements  
Sensors  
Manual

### *Process output*


Volume  
Productivity

### *Quality*

Lab measurements  
Sensors  
Customer feedback


Production management and process operators

# The BoardModel vision



$$\begin{aligned}
 &k_1^1 * \text{density} + k_1^2 * \text{surface chips} + k_1^3 * \text{wax core} + k_1^4 * \text{thickness} + k_1^5 * \text{resin core} + k_1^6 * \text{resin surf} + k_1^7 * \text{NIR} = \text{MOR} + C1 \\
 &k_2^1 * \text{density} + k_2^2 * \text{surface chips} + k_2^3 * \text{wax core} + k_2^4 * \text{thickness} + k_2^5 * \text{resin core} + k_2^6 * \text{resin surf} + k_2^7 * \text{NIR} = \text{E module} + C2 \\
 &k_3^1 * \text{density} + k_3^2 * \text{surface chips} + k_3^3 * \text{wax core} + k_3^4 * \text{thickness} + k_3^5 * \text{resin core} + k_3^6 * \text{resin surf} + k_3^7 * \text{NIR} = \text{IB} + C3 \\
 &k_4^1 * \text{density} + k_4^2 * \text{surface chips} + k_4^3 * \text{wax core} + k_4^4 * \text{thickness} + k_4^5 * \text{resin core} + k_4^6 * \text{resin surf} + k_4^7 * \text{NIR} = \text{TSW} + C4
 \end{aligned}$$

# MOR, calibrated




# Modulus of rupture

Source of error	Lab	PLS	Independent/Additive
Sample preparation	X		Yes
Precision in lab measurement	X		Yes
Sample homogeneity	X	X	No
Std dev in process parameters		X	Yes
Time lag for process tags		X	Yes
Spectrometer stability		X	Yes
Calibration error		X	Yes

# The BoardModel vision

Time series, MOR

external data set collected during 10 weeks



# Implementation

## Drivers


- Optimal quality
- Increase productivity
- Optimal raw material use
- Reduce rejects/claims




## Challenges

- Technical performance
- Relevant parameters
- Certificates
- Will it be used in the control room at 1 a.m.?
  - Company culture
  - Incentive systems
  - Trust – resistance

## Reduction of standard deviation







# Savings achieved

In €/m<sup>3</sup> when optimizing a particleboard mill  
with the BoardModel™ system

	Reference		BoardModel™	
	MOR (MPa)	IB (MPa)	MOR (MPa)	IB (MPa)
Average	21,263	0,674	20,483	0,664
Std. Deviation	1,092	0,044	0,649	0,034
Lower 5%	19,431	0,599	19,395	0,608
	n=60		n=53	
Reduced resin consumption:			7.07%	
Reduced dry wood consumption:			2.60%	
Savings:			2,82 €/m <sup>3</sup>	

**Optimization of Particleboard Production using NIR Spectroscopy and  
Multivariate Techniques**

Erik Sjöblom, Bo Johnsson\* and Henrik Sundström  
FOREST PRODUCTS JOURNAL Vol. 54, No. 6

# Moisture wood pellets



**Perten DA7200**

NIR method: 2 repacks, 2 repeats

*The sample is packed two times and scanned twice per repack.*

*This gives in total 4 spectra that are averaged to give one measured value*


*Evaluation of 85 samples*

Method	$r^2$	Std dev/SEP	# Outliers
NIR Repeat	0,999	0,016	0
NIR Repack	0,972	0,099	4
NIR Repack	0,930	0,145	0
Owen moisture duplicate samples	0,953	0,145	0
NIR- Owen moisture	0,918	0,160	3
NIR- Owen moisture	0,905	0,203	0


# Moisture wood pellets

Source of error	Owen	NIR	Independent/Additive
Weighing sample twice	X		Yes
Owen temperature	X		Yes
Particle size and shape	X	X	No
Sample homogeneity	X	X	No
Spectrometer stability		X	Yes
Sample distance		X	Yes
Calibration error		X	Yes


## Repeats




## Repack



## Owen duplicates




## Owen - NIR




# Formaldehyde

## Perten DA7400




Perforator external data




# Formaldehyde

Perten DA7400



ASTM D6007- NIR cross validation  
result, 85 samples



# Formaldehyde

Source of error	ASTM D 6007	NIR	Independent/Additive
Sample age	X		Yes
Collection of formaldehyde	X		Yes
Determination of formaldehyde	X		Yes
Sample homogeneity	X	X	No
Spectrometer stability		X	Yes
Side of board scanned		X	Yes
Calibration error		X	Yes



# Summary

- Process modelling with PLS is doable
  - Calibration works but is a challenge
  - Implementation – main challenge
- Comparing calibrated data with reference values
  - Sources of error are independent and additive
- Formaldehyde NIR calibrations
  - Calibrations with SEP compared Std error of reference method are now available

**Thank you!**